

INSTRUCTION SHEET: HSISR6SI3A TOOLLESS LINE PLUG CAT.6_A

1) Put cable through the nut.
(OD 6-8mm)

2.1) Strip off cable jacket for at least 30mm and retain a 5mm foil from cable end.
2.2) Back cover the braid then wrap the drain wire on it.

1.2 Inches min.
30.5 mm
0.2 Inches
5.1 mm
drain wire

3) Put wires through wiring management in accordance with wiring color code.

UP
I568B
4 5 7 8

4) Press wiring management to terminate wires (AWG23-26).

5) Trim excess wires (Order No.: HTOOL00002).

6) Assemble the wiring management ("UP" on the top surface) into the groove of base housing, and locate the nut in the indicated slot.

UP
I568B
4 5 7 8

7.1) Put cover into revolving groove.
7.2) Then press the cover to engage with base housing.

8) Lock and tight the nut.

DISASSEMBLY INSTRUCTION:

1) Unlock the nut.

2) Insert the slotted screwdriver into the slot and rotate to open the jaws.

3) Insert the slotted screwdriver into the slot and rotate to open the wiring management.