




## INSTRUCTION SHEET: HSEMRJ6GWT TOOLLESS KEYSTONE MODULE 10 GB / CLASS E<sub>A</sub>




Strip 26 mm of the jacket and fold braid to cover the jacket. Wrap the drain wire around the cable. The foil length of the wires passing are 3.5 mm.




Insert the wires from the stripped cable into the cap through the hole.




Insert the wires into their correct positions based upon the color code.  
Remark: Connector is suitable for AWG 22–26 solid wire. **Caution: Foil-shield of pairs may not be pressed into wire minder. Danger of short circuit when contacting.**




Cut the excess wire off as close to the edge of the cap as possible. Use straight side-cutter. (order code: HTOOL00002)




**Attention:**  
The tips of the wires have to protrude no more than 0.5 mm.




Make sure that the arrows on the jack and the cap face in the same direction.



Align the cap with the IDC towers and press it into position.




Rotate the wings toward each other until they snap closed. You hear a CLICK.




Insert the grounding wire into the grounding bar on the jack.

### DISASSEMBLY INSTRUCTION



Remove the grounding wire.



In order to remove the connector clip, insert a small screwdriver into the slot.